

# Assembly instructions for Cladding Barricade/Temporary Wall

## Steps:

1. Insert T-Track (#107) with loop side velcro into groove of frame - rubber roller makes it easier
2. Create an installation frame guide using the U-channels from the wall system kit. Attach U-channel (#386B) to outside of completed frame with mounting pins (#625)
3. Adhere hook side Velcro onto perimeter edge of PVC panel
4. Mount top panel onto frame using U-channel as a guide
5. Attach bottom panel to frame matching seam of upper panel
6. Remove U-channels. Repeat above cladding for all the front wall main panels
7. Corner assembly - Attach wing wall panel to main panel using hinge (#902) and pins (#625)
8. Stand up panels and move into position
9. Attach U-Channel (386B) onto standing panel at top, bottom, and middle
10. Install next cladded front wall panel onto standing panel
11. & 12. Attach wing panel with L brackets (#907-00) and pins (#625-00)
13. Corner assembly - Attach wing wall panel to main panel using hinge (#902) and pins (#625)
14. Mount L bracket (#907) onto another wing panel - then attach to back of side panel
15. Stand up assembly and move into position
16. Attach U channel onto upright in a vertical orientation
17. For radius corner, install hook side velcro around perimeter of the corner PVC panel - we have seamed the 8ft piece and the 4 ft piece with duct tape on the back side
18. Attach aluminum uprights that have been prepped with #107 Snap-on cover plate and loop side Velcro onto vertical edge of corner radius PVC panel
19. Stand up assembly and attach to standing panel with U-Channels & #625 pins
- 20 & 21. Flex panel into position and attach to side panel
22. Completed radius corner
23. Back of side of assembly